



P-120017 93-02 Camaro/Firebird Transmission cooler

1. Install cooler by first attaching cooler to the brackets using the supplied bolts and J-Clips. See diagram. Install on vehicle by reusing factory hardware. See photo below.



2. Remove upper transmission cooler line and screw adapter fittings both on the factory transmission line and the spot it went to on the factory radiator.
3. The radiator shroud on the passenger side will need two holes drilled for the hoses to pass thru to the cooler. A 1-inch hole saw works nice.
4. Measure and cut pushlock hose and push together hose ends. Clamps not needed. It is easiest to push one side together and route hose, then cut other end and assemble other hose end. **Note that the line coming out of the radiator will go to the bottom of the cooler and the line coming out of the top of the cooler will go back to the transmission lines.**
5. Zip tie all lines out of the way in a neat fashion.

